




Replacement Sheet



Replacement Sheet




Fig. 17

Replacement Sheet




Fig. 18

Replacement Sheet




Fig. 19

Replacement Sheet




Fig. 20

Replacement Sheet




Fig. 21

Replacement Sheet




Fig. 22

Replacement Sheet




Fig. 23

Replacement Sheet

Diebold Diagnostics							
Terminal Status	Modules	Version Info	Configuration	Metrics	Self Tests	Status Log	Service Calls
Status & Tests	Service Calls	Status Log	Version Info	Configuration	Metrics	Service Docs	
Address: D:\Techpass\BOOKSTM200001\001\1030001.htm\SS5173002							
<input type="button" value="Go"/> <input type="button" value="Help"/>							
<input type="button" value="Back"/> <input type="button" value="Forward"/> <input type="button" value="Home"/>							

4.1.2 Replacement

To replace the fascia plate, reverse the removal procedure.
Grease the gate with Diebold lubricant (PN 16-003082-000A) before

Figure 4-1 Removing the Lead-through Indicator and Exit





Fig. 24






Fig. 30

Replacement Sheet




Fig. 31




Fig. 32




Fig. 33